

2.5 Maintenance

NOTE:

For the evaporative cooler system refer to Annex 01.

2.5.1 General

It is advisable to check and readjust of the pressure switch set point when replacement of the CYL/CYL Combined High Eff. (Filter set CamPulse F8/MERV 14) cartridges when necessary.

2.5.2 Maintenance Schedule

Preventive Maintenance duties are performed weekly, monthly, every six months, yearly and every three years.

Daily Monitoring

It is recommended to monitor and record the differential pressure across the filter stage and fine filter stage on a daily basis.

The maximum recommended differential pressures are as follows:

Pulse Filter:	4.0" of WG, 1000 Pa
HEPA Filter:	2.4" of WG, 600 Pa

Weekly Record the filter resistance.

Monthly

- Inspect the filter media for signs of damage, loose fixtures and correct positioning and sealing of the gasket. Filter types should have similar color and appearance.
- Inspect the rain gutters and drains for blockage or accumulation of water
- Inspect the filter house doors for any signs of improper sealing and operation.
- Inspect the bird screen at the inlet of the filter house for any blockage.
- Inspect all flange connections with regards to damage and tightness
- Inspect external insulation and cladding for damage.

Six months

- Check the clean air plenum for degradation and moisture build-up.
- Check all gasketed joints internally for evidence of air or moisture ingress, or displacement of gaskets.

Yearly

- Check all surfaces for corrosion at least once a year and repair if needed.

Three years

- Replacement of filters, or earlier.

IMPORTANT:

Filters are considered "disposable" and therefore once used cannot be cleaned by any process. Any attempt to "clean" dirty filters for re-use is not recommended by. Possible filtration performance degradation may result. Operation conditions may dictate reduced service life.

